Sentek

Getting started with

IrriMAX Live

Your online portal to an integrated display of soil moisture, weather and irrigation data.

IrriMAX Live User Credentials



File Message	Insert Options Format Text	Review			
Cut Copy Paste Format Pair	• 12 • A A E ≡ ter B I U ® I A A ≡ ≡		Attach Attach Signature	Follow Up ▼High ImportanceLow Importance	Zoom
Clipboard	□ Basic Text	□ Names	Include	Tags 🗔	Zoom
Fro <u>m</u> ▼ Send Fro <u>m</u> ▼ To <u></u> Cc Bcc Subject:	Welcome to IrriMAX Live				

Hello Jenny Farmer,

Your IrriMAX Live account has been created with the following credentials:

Username: jfarmer Password: BfysKMO7po


To login, visit https://www.irrimaxlive.com and enter the credentials above. When you have signed in, you can access your settings and change your password.

To learn more about using IrriMAX Live, visit our YouTube channel at https://www.youtube.com/playlist?list=PLYrEZZgKDUPY9w9F7q13glxkYjDEMG0q4

IrriMAX Live is brought to you by Sentek http://www.sentek.com.au

Sign in






Create 'App Shortcut' for IrriMAX Live





















■ IrriMAX Live





















- n Default home view
- ♠ Mixed map view
- ♠ Mixed alert list view
- ♠ Mixed % available list view
- **▲** Make this your main view
- ♠ Go to the old version


















User Menu

Contains functions relating to your account, including the **Sign out** command



Contains basic navigation and view options, **Help** and **News** links





Loggers **Folder**

This is your Loggers folder, containing logger databases and their default graphs. An orange circle shows the number of alerts raised inside the folder.

Graph Folder

Folders may be created for the purpose of organizing the graphs.


Graph

The graphs in the current folder will be presented differently depending on your viewing options. The thumbnail view shown below is the default option.

Potato_-15

Probe01_Voltage

Potato_0



Left: shows your place in the hierarchy eg.

Navigation Bar

Home > Logger folder name > Graph name

Right: File Menu and View Menu (Homepage View)

Graph Menu, Logger Menu and Zoom Menu (Graph View)









Create a New Graph




















Cancel

Home sentekdemo001 Graph Logger All data







Use the **Graph Menu** to modify the graph

Home sentekdemo001

- Place rulers: Select on the graph to place temporary vertical rulers, which display values at those points. Remove all rulers by choosing Clear in the navigation bar.
- 2D image: Select two or more loggers installed side-by-side to display moisture, salinity or temperature in an isometric-style view of a vertical slice of soil. To set up your **2D image**, first create a pane for each logger, then choose this option..
- **Edit comments:** Select any point on the graph to add a comment.
- Set full point: Select within a pane to set the Full budget line, or choose Clear to remove it. When you have set a full point, IrriMAX Live will automatically generate an alert if the last reading is above the line.
- Set refill point: Set the Refill budget line in the clicked pane. An alert will automatically be generated if the last value is below this line.
- Set stress point: Set the Onset of Stress budget line in the clicked pane. An alert will automatically be generated if the last value is below this line.
- Add or edit growth stages: A Growth Stage is a labeled time from which a different set of budget line values can be set.
- Remove growth stages: Select within a Growth Stage to remove it from the graph.
- Calibration/temperature fix: Recalculate any soil water values with a different calibration. Ensure the calibrations stored against the sensors in the logger database must be accurate. This means they must be explicitly defined, or if undefined, the probe must have calculated the values using the **Default Sentek Calibration**
- Replace graph: Replace a graph with a new graph, retaining the current name and using the logger database currently in the bottom pane. All secondary panes will be discarded, as will comments, growth stages etc.
- Add pane: Select sensors from any logger database you have access to, and graph them in a new pane, stacked on top of all existing panes.
- Remove pane: Select on a pane to remove it from the graph. You can't remove the bottom pane.
- Copy pane: Copy a pane from the graph
- Paste copied pane: Paste your copied pane as a new pane on the current graph, or paste the budget lines and growth stages on another existing pane
- Paste budget lines: Paste the budget line values and growth stages from your copied pane into an existing pane. This replaces any existing budget lines and growth stages.
- Change pane heights: Select a pane to enlarge it over another pane. You can also undo this action and make pane heights equal.
- Download package: Creates a download package containing the graph and the underlying logger databases. This package can be opened in the IrriMAX desktop software (version 9.1 or later.)
- Upload IrriMAX graph: If you have downloaded this graph to the IrriMAX desktop software and modified it there, then you can select this option to upload your changes. The current graph will be replaced with the graph you upload. The filename and internal signature of the logger database in the bottom pane must match the original on IrriMAX Live.

Graph Logger All data

I Place rulers



Edit comments

Set full point

Set refill point

Set stress point

Add or edit growth stages

Remove growth stage

Calibration/temperature fix

• Replace graph

Add pane

Remove pane

Copy pane


Paste copied pane

Paste budget lines

Thange pane heights


Download package

Upload IrriMAX graph




Example: setting Budget Lines

Click within a pane to set the full point.




Example: setting Budget Lines

Home sentekdemo001




Example: setting Budget Lines



Example: setting Budget Lines


Click within a pane to set the stress point.

Clear stress 🗙



Example: setting Budget Lines

Home sentekdemo001



Example: setting Budget Lines



Navigating a Graph









Probe01 rootzone





Probe01_Summed and stacked




Probe01_Summed rootzone





















^{↑™} Sort by last update



Probe01_Voltage


^{↑™} Sort by last update






Gauges view

^{↑®} Sort by last update



List view



Jenny Farmer (Farmer and Co.)

Any current view can be stored as your Main View. This is the view you will see whenever you sign in. This action can be made from the Main menu.





Getting Started

- . Add IrriMAX Live to your device's Home screen for a much better user experience on Android and iOS.
- · List of changes in the new version

Using IrriMAX Live

- · Terminology and basic concepts
- · Main menu and User menu commands (Available site-wide)
- Folder views (Home, Loggers and user-created folders)
- Folder viewing options (Thumbs, list, map, sorting etc)
- · The graph view

Advanced Topics

. Extract data from IrriMAX Live using our API, to import into other systems or update a local copy of a database for use with the IrriMAX Windows software.

Legal

- Privacy policy
- · Terms and conditions of use

Further Help and Information

Select **Help** from the Main menu for more information relating to news, updates and advanced topics



Please get in touch if you need further training. 1:1 online meetings can be arranged to assist our dealers with learning IrriMAX Live.

Regional Managers sentek@sentek.com.au +61 8 8366 1900

f Sentek Technologies

sentek_technologies

@sentektech

SentekVideos